Akuvox Smart Intercom

Unpacking

Before you start using the device, please check the version you have received and ensure that the following items are included in the shipped box:


Mainframe Accessories :

manna	ne Accessones i				
	X915 x 1	Rubber plug (small) x 2	ित्रित्ये Rubber plug (medium) x 2	Wiring cover x 1
An Fil	Rubber plug (large) x 2	Sealing ring x 1	M3x4 crosshe	ad screw x 6 ———	Diode x 3
	= Torx wrench x 1	Card reader touch plate x 1	O- Plate remova	l key x 1 🛛	Rope x 1
	2x6-PIN terminal block x 1	2x5-PIN terminal block x 1	2-PIN termina	al block x 1 🖵 🗖 🛱	Pry bar x 1
\$	M3x9.5 torx head screw x 2				
Flush-mo	ounting Accessories (Please fin	d in In-Wall Installation Kit k	oox):		
1.0¥	Flush-mounting box x 1 🕀 🖯	ST4x35 crosshead scre	ew x 4 🛞 📴	Plastic wall anchor x 4	
Wall-mo	unting Accessories (Please find	l in On-Wall Installation Kit k	юх):		
	Wall-mounting box x 1 🛛 🕀 🗍	M4 x 30 crosshead s	crew x 2 🕀 🕂 🎹 🎹	 ST4 x 20 crosshead scr 	ew x 4
H	🜐 Plastic wall anchor x 4				
Prod	uct Overview Face	e-liveness Detection Camera	Camera		
		ed LED		red LED e Light LED	
	White Lig		ЭЦО — міс		
			e]		
		12:34 мл wed 3-4 ● Community 1 Выйслар 65 - JinShan r			
		English Eespañol Po	есия ФХ		
			Touch	n Screen	
		4015			
			Call		
		Tenants	Reception		
				ed Sensor	
				peaker	
		(((=)))	Card F	leader	
		YO	15X		

Installation Environment

Please do not place device under direct sunlight.

If installing the device indoors, please keep device at least 2 meters away from light, and at least 3 meters away from window and door.




Attention:

Biometric recognition product may not be 100% accurate and applicable to all scenarios and enviroment. For higher security purpose or scenario, please set up access authentication combination.


Installation Step 1: Wall-mounting Box or Flush-mounting Box Installation

1. Wall-Mounting


1.1 With 86x86 mm embedded junction box in the wall



Fix the wall-mounting box on to the embedded box (86) with two M4x30 crosshead screws, mark the positions of the four holes of the wall-mounting box at the hole center.




Take off the box and drill the four marked holes using 6 mm drill bit hand drill before inserting the plastic wall anchors into the drilled holes.




Place the wall-mounting box closely against the wall while lining up its four holes with their corresponding drilled holes and then fix the wall-mounting box on the wall by tightening the four ST4x20 crosshead screws and two M4x30 crosshead to the plastic wall anchors.


1.2 Without embedded junction box in the wall



According to the position of the wire on the wall, put the wall-mounting box closely on to the wall and mark the four positioning holes, while making sure that relative positions between wall-mounting box and wiring hole are correct.



Drill the marked holes using 6 mm drill bit hand drill before inserting plastic wall anchors in to the drilled holes.




Place the wall-mounting box closely against the wall while lining up its four holes with their corresponding drilled holes and then fix the wall-mounting box on the wall by tightening four ST4x20 crosshead screws and two M4x30 crosshead screws to the plastic wall anchors.


Note: It is recommended that you keep the bottom side of the square hole 10mm away from the wiring hole on the wall as indicated in the figure.




X915X Quick Guide


2. Flush-Mounting







Break off the round knock-out wiring holes and lead the wires through the corresponding hole in to the flush-mounting box, then press the flush-mounting box in to the square hole. The upper and lower folded edges of the flush-mounting box must fit snugly against the wall. Then fix the box using the four plastic wall anchors and the four ST4x20 crosshead screws.



Make sure that the flush-mounting box are well tightened and its upper and lower folded edges are fit snugly against the wall, fill in the gap between the wall and the flush-mounting box using cement or non-corrosive structural adhesive and wait until the cement is hardened before proceeding to the next step.


(height*width*depth = 337*122*57 mm).

Cut out a square hole


with the dimension

Insert the flush-mounting box in to the hole and mark the the positions of the four holes of the flush-mounting box on the wall, then take off the box and drill the holes on the marked positions using 6 mm drill bit hand drill before inserting the plastic anchors in to the drilled holes.

STEP 2: Wiring Cover Installation




Hang the one end of the rope on to the square hanger on the wall-mounting/flush-mounting box then hang the other end of the rope on to the square hook on the device for the convenience of the later wire installation etc.




Connect the wires to the terminal blocks as needed (for details, refer to "Device Wiring"), then insert the terminal blocks into the corresponding interface of the main board as indicated in the drawing according to the number of PIN.

Note: The pry bar attached can be used to unplug the terminal blocks if needed.





Choose a suitable size rubber plug (small, large and medium) to hold down the wires, while tearing off the adhesive sticker on the selected rubber plug and stick it on to the X915 wiring cover and then tear off the adhesive sticker on the other rubber plug of the same size and stick it on to the wiring cover in the position as indicated in the drawing.




Press wiring cover and sealing ring into the corresponding groove as indicated by the arrow and then tighten the wiring cover by six M3x4 crosshead screws.

STEP 3: Device Mounting






Take off the rope and hang the device on to the two square hangers on the wall-mounting/ flush-mounting box.Stick the plate removal key in to the small hole on the upper left corner of the card reader touch plate to pull out the plate.



Drive the two M3x9.5 torx head screw in to their corresponding holes.




Press the card reader touch plate in to the card reader opening.



Installation is completed, please remove the protective film.

Akuvox Smart Intercom




Wire Length & AWG Table

Please follow the properly measured wire gauge/length to install device:

	12 AWG	14 AWG	16 AWG	18 AWG	20 AWG
24V 2A Adapter	≪40m	≤30m	≤20m	≤10m	≤5 m

Application Network Topology



Configuration

1.IP address Checking: Press 9999 on the dial screen, then press 3888 to enter the system screen and click **Info** to check the device IP address. X915 uses DHCP by default.

2.Account Registration: On the device, go to Setting > Account to enable the function and fill in the account information, then click Submit. (Please refer to user manual for more information).

Operation

Make a call:

Enter the IP or SIP number and press Dial tab to make a call.

<u>Receive a call:</u>

X915 supports Auto Answer by default. Incoming call from indoor device will be answered automatically.

Unlock by PIN:

Click **PIN icon** to enter **PIN** code for the door access.

Unlock by RF Card:

Place the configured RF card on the RF card reader area for the door access.

NOTICE:

Quick guide can be viewed on Global Visions website.

GLOBAL VISIONS INC. 877-725-8869 www.globalvisionsinc.com



