# Get Started With Training Kit



### 1. Power On

• Akuvox training kit has built-in power supply. You can connect power plug cord to power connector. Press power switch to turn on.

<sup>\*</sup>Akuvox doesn't provide power plug cord.



### 2. Setup Network

• Akuvox training kit supports Wi-Fi and wire network connections.

#### Wire Network Connection

Use network cable to connect your uplink port on bottom of the training kit.





After that training kit can access network automatically.

Wi-Fi Network Connection



Connect 360WiFi-\*\*\*\*\* on your Personal Computer or Mobil Devices





### 3. Cloud Activation

• Please email us the following informations;

Name:

E-mail adress:

Device mac adresses:

Company name:

help@blvs.com

Click this button for more resources



## Back to Global Visions Akuvox Knowledge Base

