

Akuvox Debug Tool [retrieve passwords for local devices] - [Download Link](#)

Step:

1. Install IP scanner: [Download Link](#)
 2. Download SDMC DEBUG TOOL. (Must download it after installation of IP SCANNER done.)
 3. Run SDMC Debug Tool.
 4. Run IP SCANNER.
 5. Click the unit you want to check its password,
 6. You can find its current password on SDMC debug tool.
- (If you cant see the password, best to refer to the log and you can just ctrl+f and search "password" and find it)

Click this button for more resources



**Back to Global Visions
Akuvox Knowledge Base**

