AKUVOX Smart

R27X Quick Guide

Unpacking

Before you begin using the device, please check the version you got and ensure that the following items are included in the shipped box:

Mainframe Accessories:



Akuvox Smart

R27X Quick Guide

Installation Environment

Indoor and outdoor installation are supported.

If installing the device outdoors, please don't place device under direct sunlight, it will bring a bad effect or be broken with the high temperature.

If installing the device indoors, please keep device at least 2 meters away from light, and at least 3 meters away from window and door .







Direct sunlight



Direct sun through window



Indirect sunlight through window



Close to light

Installation

Step 1: Bracket/Box Installation Wall Mounting With 86 embedded box in the wall



Fix the wall-mounting box on 86 embedded box with two M4x30 screws.



Fix the wall-mounting box with four ST4x20 screws and two M4x30 screws.



Mark the four holes of the wall-mounting box on the wall.



Insert the plastic wall anchor into the holes.



Take down two M4x30 screws and wall-mounting box.



Use a hand drill with 5mm diameter bit to make holes in the marked positions.

Akuvox Smart Intercom

R27X Quick Guide

Without 86 embedded box in the wall



Mark the six holes of the wall-mounting box on the wall.



Use a hand drill with 5 mm diameter bit to make the hole in marked positions. Dig out a square hole.(height*width*depth=80*60*50 mm)

*Please note the relative position in the left figure and the maximum error should less than 5 mm.



Insert the plastic wall anchor into the holes you drilled before.



Fix the wall-mounting box with six ST4x20 screws.

Flush Mounting



Dig out a square hole

(height*width*depth=262.5*121*60 mm). Note:The size of the hole should be a little larger than recommended value that can accommodate all cables.



Use six M4x10 screws to fix the flush-mounting bracket on the embedded box.



Insert the embedded box into the hole and make sure the cables of the device can route through the cable hole. Then mark the six holes of the wall embedded box on the wall.



Take down the embedded box, then use a hand drill with 5mm diameter bit to make holes in the marked positions.



Place the embedded box into the square hole until the edges of which align to the wall and make all cables go through the cable hole. Fix the embedded box with six ST4x20 screws.

Note: The embedded box can not over the edge of the square hole.



Insert the plastic wall anchor in the hole you drill before.

Akuvox Smart Intercom

R27X Quick Guide

Without ST4x20 screw, please follow the below installation method.



(height*width*depth=262.5*121*60 mm).

Note: The size of the hole should be a

little bigger than recommended value

that can accommodate all cables.





Use cement or non-corrosive structural adhesives to fill the gap between the wall and embedded box. Wait the adhesive material desiccation, go to the next step.



Use six M4x10 screws to fix the flush-mounting bracket on the embedded box.

Step 2: Back cover Installation



Dig out a square hole





Use four M3x5 screws to fix the back cover.

For convenient wiring, hang R27X on the wall-mounting box/ flush-mounting bracket with rope. Then insert the silicon rubber sealing ring into the groove.

Step 3: Device Mounting





 Place the device into the wall-mounting box/ flush-mounting bracket until the edges of which align to the wall. Then pull the device downward and ensure the groove of it hooks to the lock catches of the back box.

2.Use the Allen wrench to tighten the device with two M3x6 screws.

Wall Mounting



R27X Quick Guide

Application Scenario



Device Wiring



Akuvox Smart Intercom

R27X Quick Guide

Conguration

1.IP Address Checking: Press *2396# to enter administrator setting interface. Click **System** *Information* to get the IP address. R27X uses DHCP by default.

2.Account Registration: On web UI, go to the path: Account -> Basic page to register account and fill in the account information. (Please refer to user manual for more information)

3.DTMF Code Configuration: On web UI, go to the path: *Intercom -> Relay -> Relay ID/DTMF* and choose the DTMF code number in corresponding area.

Operation

Make a call: Input the room number, press Dial key to make a call.

Receive a call:

R27X supports Auto Answer by default. Incoming calls will be answered automatically.

Unlock by DTMF:

During the call, press the corresponding DTMF code of answer unit to unlock R27X remotely.

Unlock by Private Key:

In the idle, enter " **# + password + #**" or " **password + #**" to open the door. (The latter is used for New version. Go to **web UI - Intercom - Basic - Display Type** to switch Old or New version UI.)

Unlock by RF Card(Optional):

Place the predefined RF Card in the RF reader area to open the door.



NOTICE: Quick guide can be viewed on Global Visions website.



GLOBAL VISIONS INC. 877-725-8869 www.globalvisionsinc.com

